

PWK Jetting Courtesy Bill Getty September 2010								
make	pilot	needle jet	needle	needle position	main	elevation	unit	Special instructions
BSA A10 650	35	std	std	center	125	2000	30mm	
BSA A65T	35	std	std	center	118	2200	30mm	
BSA A65L	30	std	std	center	130	2200	30mm	
BSA B25	25	std	std	center	110	2200	26mm	
BSA B44	30	std	std	center	135	2200	30mm	
BSA B50T	30	std	std	bottom	130	1000	30mm	
BSA B50MX	35	std	std	bottom	140	1000	30mm	
Triumph T100C	30	std	std	center	115	2200	30mm	
T100R	30	std	std	center	110	1000	26mm	
TR6/T110/6T	35	std	std	center	135	2200	30mm	
T120	35	std	std	center	137	2200	30mm	
TR7	40	std	std	center	140	2200	30mm	
T140	40	std	std	top	130	2200	30mm	
T160	30	std	std	top	110	2200	26mm	
T20 Cub	25	std	std	top	90	2200	26mm	
Moto guzzi 850	38	std	std	center	130	2200	30mm	
Velocette 500	35	std	std	bottom	140	1000	30mm	
Vincent 1000	40	std	std	center	140	1000	30mm	
Norton 750 com	35	std	p11/32	Center	132	2200	30mm	
Norton 850 com	35	std	p11/32	center	132	2200	30mm	
Norton 850 com	35	std	p11/32	center	132	2200	32mm	Special manifold
Norton single carb	40	std	p11/32	top	130	2200	32mm	Special manifold
Matchless 650	35	std	std	center	135	1000	30mm	
Ariel 4 cylinder	40	std	std	center	140	1000	30mm	
Ducati 250	40	std	std	center	135	1000	30mm	